



PASSENGER
Ground to 700
17
Ground to 700
16
PASSENGER

FREIGHT
Ground to 500
18

SERVICE
Ground to 500
1

PASSENGER
Ground to 650
2
Ground to 650
3
PASSENGER

650 to 700
22
PASSENGER
GROUND to 400
15

650 to 700
19
PASSENGER

GROUND to 400
4
PASSENGER
(PREMIUM ACCESS ONLY)

GROUND to 400
5
PASSENGER
(PREMIUM ACCESS ONLY)

PASSENGER
(PREMIUM ACCESS ONLY)
14
GROUND to 400
13
PASSENGER
(PREMIUM ACCESS ONLY)

GROUND to 400
6
SERVICE

GROUND to 400
6
SERVICE

650 to 700
20
PASSENGER

650 to 700
21
PASSENGER

PASSENGER

PASSENGER
Ground to 700
12
Ground to 700
11
PASSENGER

10
Ground to 500
SERVICE

9
Ground to 500
FREIGHT

PASSENGER
Ground to 650
7
Ground to 650
8
PASSENGER

